

NEW!

Round LVR1 Low Voltage Mounting Bracket

Easy Installation of Smoke Detectors and More!

LVR1

- Adjusts to fit 1/4" to 1-1/2" thick wall or ceiling thickness
- Bracket is its own template for cut out. Trace hole along the inside diameter of the bracket. Cut along the outside of the line.
- UL, CSA Listed

Fast and Easy Installation of a Smoke Detector

- 1 Trace bracket, then cut hole.
- 2 Pull wires.
- 3 Insert bracket into opening.
- 4 Tighten three screws to set LVR1 "wings" securely against drywall.
- 5 Attach smoke detector to LVR1 through screw holes in the mounting plate.
- 6 Attach smoke detector cover. Done!



LVR1
Round Low Voltage
Mounting Bracket



Arlington
1 Stauffer Industrial Park
Scranton, PA 18517
800/233.4717
Fax 570/562.0646
www.aifittings.com

©1999 - 2007 Arlington Industries, Inc.

Distributed by

Patented.

LV1 to LV4, LVR1 1107/50M