




**IRE1TB/IRE2TB
INFRARED EMITTER
Information and Installation Guide**


Features:

1. Elegant, round shape with compact size
2. Transparent housing
3. 10 foot cable length
4. Self adhesive tape for quick and easy mounts to hard, clean and dry surfaces
5. Status Indicator

Diagram




**Installation
Standard installati**




Attach IR emitter at inside of shelf

1. IR emitter (flat side) attached directly to IR sensor window
2. More reliable activated
3. Looks nice



Cabinet With door Installation

1. Attach IR emitter on above or below of the IR window
2. Less reliable activated



1. IR emitter is attached to rack door, round shape side facing the IR window
2. Less reliable activated

Note:

1. Make sure mounting surface is clean and dry for proper installation
2. Can not connect IR emitter directly to power supply or battery